

PREPARATORY FUNCTION


G00	RAPID POSITIONING
G01	LINEAR INTERPOLATION
G02	CW CIRCULAR INTERPOLATION
G03	CCW CIRCULAR INTERPOLATION
G70	DIMENSION IN INCH
G71	DIMENSION IN MM
G75	RETURN TO HOME
G90	ABSOLUTE DIMENSION
G91	INCREMENTAL DIMENSION


PREPARATORY FUNCTION FOR MOVEMENT G00, G01, G02,...
PREPARATORY FUNCTION FOR PRESETTING G70, G90, G91,...

MISCELLANEOUS FUNCTION

M00	PROGRAM STOP
M01	OPTIONAL STOP
M02	PROGRAM END WITH OUT RESET
M03	SPINDLE ON CW
M04	SPINDLE ON CCW
M05	SPINDLE STOP
M06	TOOL CHANGE
M08	COOLANT ON
M09	COOLANT OFF
M30	PROGRAM END WITH RESET

N	SEQUENCE OR BLOCK NUMBER
T	TOOL SELECTION
S	SPINDLE SPEED IN RPM
F	FEED IN mm/rev
CR	RADIUS OF CIRCLE





PROGRAM G75 X0 Z0 T1 D1 G96 S200 LIMS=1500 M03 M08 G00 X36 Z2 CYCLE95("AB:BC",1,0.2,0.4,0,0.15,0.1,0.05,9,,,) G00 X36 Z2 G75 X0 Z0 M05 M09 M30 AB: G01 X0 Z0 F0.1 G03 X12 Z-6 CR=6 G01 X12 Z-9 G01 X16 Z-9 G01 X20 Z-11 G01 X20 Z-21 G02 X26 Z-24 CR=3 G01 X30 Z-24 G01 X30 Z-30 G01 X32 Z-30 BC:

MACHINE ON

- MAIN PANEL ON
- STABILIZER ON
- RESET BUTTON PRESS (STABILIZER)
- MACHINE MAIN POWER ON

RUNING SET UP

- EMERGENCY RELEASE
- RESET (EMERGENCY)